


LetB

COLOR

Thank you for your support!



Rear view



Front view

To start using LetB:

1. Plug in power supply to the socket at the back of the clock (bottom right)
2. Set time using two buttons at the back. To change hour press and hold hour button until desired hour will be displayed. Similarly proceed with minute button to change minutes.

Remote Control with iPhone

To control LetB with iPhone:

1. Download **HM10 Bluetooth Serial** app.
2. Open app and in the tab **Connect**, connect to LetB
3. Available options will be displayed.
Type and send corresponding number to change settings.

Remote Control with Android Phone

To control LetB with Android Phone:

1. Download **Serial Bluetooth Terminal** app and proceed similarly.
2. Before using the app change parameter in **Settings > Send > Newline > None**.

