


LetB

BASIC

Thank you for your support!



Rear view



Front view

To start using LetB:

1. Plug in power supply to the socket at the back of the clock (bottom right)
2. Set time using two buttons at the back. To change hour press and hold right button until desired hour will be displayed. Similarly proceed with left button to change minutes.